

# Breath In The Nature

C1A is a new generation desktop air purifier, which used the latest double fans air duct circulation system and bamboo fiber HEPA filter and designed to remove PM2.5, smoke, allergy, TVOC, pollen and also can remove bacteria and virus in the room air. It is widely used in office, baby bedroom, airplane and coffee shop. It has LCD display which can real-time display the room air quality situation like PM2.5, temperature and humidity etc.



PM2.5<10



5 million  
negative ions



45m<sup>3</sup>/h



19.3m<sup>3</sup>/H



<50dB





## 01 New Latest Air Duct System

New technology air duct system, three sides of air inlets, two air outlets, which can quickly complete room air circulation and air balance. It can quickly create PM2.5 <10 fresh air room environment.

## 02 Latest Bamboo Filter HEPA + Bamboo Charcoal Composited Filter

The filter inside adopted latest technical filters, which is consist of bamboo fiber layer+ HEPA filter layer+ bamboo charcoal layer composited filter. It can quickly remove PM2.5, smoke, bacteria, TVOC, formaldehyde and other harmful substances.



Bamboo fiber HEPA filter + Bamboo Charcoal



Air Duct System

## 03 Negative Ions Purification

Adopted micro negative ions technology, release **5 million** highly-activated and small particle negative ions, which can move longer distance and have excellent to remove PM2.5, smoke, pollen, bacteria and virus.

## 04 Real-Time Display



AIQ display



Product model	Desktop Air Purifier
Colour	Dark Red/ Silver White
Efficient area	up to 15m <sup>3</sup>
Particle CADR	45 m <sup>3</sup> /h
Sterilization rate	99.9%
Formaldehyde CADR	19.3 m <sup>3</sup> /h
Micro negative Ions	5 million pcs/cm <sup>3</sup>
power	DC 12V
Wattage	7W
Size	130 x 130 x 340 mm
Net weight	1.5 kg
Noise	< 50dB